

Forklift Pre-Operational Check

(Power Turned Off)

Name:	Dept:						
Date:		Make:					
Hours Used:	Serial #:						
Overall Check — Outside the Forklift							
Checklist Items	Yes	No	Follow -up	Comments			
Leaks —Signs of fluid leaks under or around forklift.							
Structural Components – Tightly secured, no broken welds, free from dents, damage, excessive rust, corrosion, and wear.							
Rims – Free of distortions and cracks. Nuts in place and tightened.							
Tires – Sufficient tread and free from cuts, gouges, and foreign objects.							
Tilt Cylinder/Lift Chain — Bolts in place and tightened for cylinders. Chain in good condition and lubricated.							
Mast/Strip Surfaces — Sliding surfaces and rollers are free from cracks and excessive wear. Rollers move smoothly.							
Backrest/Extension — In good condition, free of distortion, cracks, other defects, and excessive rattle.							
Forks – Free of cracks/defects. Both forks are same height and position when setting on ground. Fork tips not worn thin.							
Assist Grip — No visible signs of damage or cracking. Screws in place/tightened.							
Overhead Guard — Bolts are in place and tightened. Guard is free of bent or cracked sections. Overhead view is not obstructed.							
Light Covers – Clean and not cracked or missing.							
Hydraulic Fluid – Fluid at proper level. No signs of overflow or leaks. Cap in place and secure. Hose fittings and cylinders are in good condition.							

Engine Oil – Full on dipstick, no leaks, and filler cap is secure.							
Fuel – No leaks, tanks are secure, no visible signs of damage to tank, valves, or hoses and fuel at proper level.							
Battery — In good condition, not leaking, and free of damage. Electrolyte at proper level.							
Overall Check — Seated Position							
Checklist Items	Yes	No	Follow -up	Comments			
Seat Assembly — Slides freely forward and back. Lever holds seat in place.							
Seat Belt - Easily extends from and re-tracks into holder. Belt is free of cuts, brakes, or tears. Buckle securely fastens.							
Parking Brake - Lever moves freely.							
Steering Wheel - Securely mounted to steering column and free from damage.							
Pedals – Covers installed and free from binding or rubbing when depressed or released.							
Levers – In good condition and work without binding or restriction. Rubber boots installed and free of cracks/breaks.							
Instrument Panel – Cover in place and good condition.							
Decals/Labels/Capacity Plates - In good condition and legible.							
Operator's Manual — Available, in good condition and placed in the holder.							